

TECHNICAL DATA SHEET

Maintenance Light Duty Mats



CODE: **24-AM111**

General purpose absorbent sheets

An effective absorbent sheet for use in the event of spills involving water or oil based products, suitable for use in most industrial applications. Being light and easy to handle they are easily deployed in quantities relevant to the spill size, therefore avoiding the waste associated with granular absorbents. They can easily be disposed of once saturated and are useful when used around leaking machinery.

Benefits:

- Light and easy to deploy
- Cost effective
- Melt blown for high absorption rates
- Absorbs without leaving messy deposits
- Absorbs both oil and water based spills
- Durable and resilient outer covering
- Leaves the floor drier
- Low linting
- Dimpled for better cohesion and strength
- Perforated for economic use

Technical Data:

Appearance:	Grey perforated and dimpled fibrous sheet
Material:	Melt blown polypropylene
Dimensions:	50 x 40cm
Density:	180g/m ²
Absorbency:	Approx 0.65 litres per sheet depending on product to be absorbed
Saturation Time:	Approx 20-30 seconds for 10W/40 engine oil
Quantity:	200 per pack
Directions for use:	Suitable protective equipment should be worn. Lay sheets sufficient to cover the spill. Leave until saturated and dispose of in line with local and national regulations.