

## TECHNICAL DATA SHEET

# Maintenance Medium Duty Mats



CODE: 24-**AM112**

Maintenance absorbent sheets

An effective absorbent sheet for use in the event of spills involving water and oil based products, suitable for use in most industrial applications. Being light and easy to handle they are easily deployed in quantities relevant to the spill size, therefore avoiding the waste associated with granular absorbents. They can easily be disposed of once saturated and are useful when used around leaking machinery.

Benefits:

- Light and easy to deploy
- Cost effective
- Melt blown for high absorption rates
- Absorb without leaving messy deposits
- Absorb water and oil based spills
- Perforated for economical use
- Dimpled for extra strength
- Leaves the floor dry

### Technical Data:

Appearance: Grey perforated and dimpled fibrous sheet  
Material: Melt blown polypropylene  
Dimensions: 50 x 40cm  
Density: 280g/m<sup>2</sup>  
Absorbency: Approx 1 litre per sheet depending on product to be absorbed  
Saturation Time: Approx 60-90 seconds for 10W/40 engine oil  
Quantity: 100 per pack. AM181 packed 40 in a handy dispenser box, 3 boxes per pack  
Directions for use: Suitable protective equipment should be worn. Lay sheets sufficient to cover the spill. Leave until saturated and dispose of in line with local and national regulations.