

BIO MIX

Biological Grease-Trap and Drain Maintainer

DESCRIPTION

Bio Mix is a dry powder containing selected micro-organisms and enzymes, that efficiently reduce the wastes typically evacuated into the drainage systems of kitchens and other catering and food processing units. Bio Mix is suitable for use in all types of drains, sinks and small-bore pipes, as well as for maintaining septic tanks, grease traps and complete sewerage systems.

Bio Mix has a two-stage operation. When activated with water, the 'free' enzymes quickly break down the waste into smaller pieces, which are more accessible to the micro-organisms. This initial degradation immediately improves drain flow-rates and reduces odours. It also enables the various strains of micro-organisms in Bio Mix to quickly continue the degrading process, further reducing the particles of solid waste (such as fat, paper and vegetable trimmings) into liquids and gasses.

FEATURES AND BENEFITS

- § **Liquifies fats and grease**
- § **Neutral PH of 6.5 – 7.5**
- § **Effective on all types of drains and small-bore pipes**
- § **Maintains septic tanks, grease traps and complete sewerage systems**
- § **Reduces odours**
- § **Improves drain flow-rates**
- § **Will not damage the drainage system or environment**



TECHNICAL INFORMATION

Bio Mix contains many strains of non-harmful micro-organisms, typically 500,000,000 units per ml. (5 x 10⁸) Bio Mix is a tan powder with a very slight yeast fragrance.

PACKAGING

<i>code</i>		
BM 500	BIO MIX	10 X 500g
BM 2.5	BIO MIX	2.5 kg

STORAGE

Bio Mix is stable for a minimum of 12 months if stored in it's original, sealed container, in a DRY LOCATION, away from direct sunlight. Bio Mix is not harmful or irritant under CHIP or COSHH.

DIRECTIONS

For Sinks, Baths, Showers, Urinals and Waste Outlets

Starter Dose – 25g each. Maintenance – 25g per month

For Interceptors, Grease Traps, and Septic Tanks

Starter Dose - 50g per 100 litre capacity, Maintenance 25g per 100 litre capacity per week

For Soakaways

Starter Dose - 100g per 1000 litre capacity, Maintenance 25g per 1000 litre capacity per week

Disinfectants, bleach caustic and acid products will adversely effect the biological action of Bio-Mix.

Drainage systems cannot be damaged or overdosed by this product.