

CITRA CLEAN® Orange Squirt

Powerful **READY TO USE**

All Purpose Cleaner and Degreaser

DESCRIPTION

Orange Squirt is a concentrated multi-purpose cleaner containing natural orange terpenes, which leave a pleasant orange fragrance after use. Orange Squirt's unique formulation is free from petrol and chlorinated based solvents, with a neutral PH of 8-8.5 making it one of the gentlest but most versatile cleaners available.

FEATURES AND BENEFITS

- § Biodegradable
- § Quick splitting
- § Contains advanced surfactant technology
- § Water soluble liquid
- § Neutral pH of 8 - 8.5
- § Powerful and dilutable

PACKAGING

code

OS5 ORANGE SQUIRT 4 X 5L

OS750 ORANGE SQUIRT 6 X 750 ml trigger

STORAGE

Store in original container
Keep tightly closed when not in use.
Keep out of reach of children.

DIRECTIONS

Dilute as necessary to required strength. Spray, mop, swab or brush on to soiled area, agitate and wipe clean. For heavily soiled areas agitate and leave to work for a few minutes. Spray on and wipe off. No need to rinse.
Avoid long term use with polished aluminium.

DILUTION

Orange Squirt is ready to use neat or may be further diluted as follows

LIGHT EVERY DAY CLEANING

Dilute up to 50:1 with hot or cold water

GENERAL CLEANING

Dilute up to 20:1

INK, GREASE AND OIL

Dilute up to 10:1

FLOOR POLISHES AND ADHESIVES

Dilute up to 10:1

Test for colour fastness before using on fabrics.



APPLICATIONS

Use on all washable surfaces, carpets and fabrics including terrazzo, stainless steel and colourfast upholstery products.

Ideal in schools, hospitals, & institutions and where selection of safer cleaning agents is important.

USE TO REMOVE

Tar, grease, baked-on carbon, wax, soot, oil, ink, toner, adhesives, sealant, glue, polish, fat, wax, crayon, blu-tac, plasticine, lipstick, chewing-gum, smoke damage, nicotine, scuff marks, tyre marks, body-fats, sweat, finger-marks, traffic film, insects, & even some graffiti. **Safely strips all types of floor polish & adhesives without damaging the flooring.**

CLEANS

KITCHENS walls, floors, filters, cooker-tops, ovens, worktops, griddles & all hard surfaces.

SHOPS OFFICES AND PUBLIC BUILDINGS carpets, upholstery, plastic & melamine, chrome, ceramic tiles, lino, terrazzo, paintwork.

SPORTS AND AMENITY CENTRES showers, ceramic tiles and swimming-pool surrounds, washrooms, carpeting, terrazzo, vinyl, marble, chrome, stainless steel, paintwork, patio furniture, bar-b-q's, bouncy-castles.

AUTOMOTIVE, MARINE, WORKSHOPS & ENGINEERING engines, paintwork, wheels, plastic trim, chrome, upholstery & carpets, vinyl, canvas, concrete floors, metalwork, machinery, tools & equipment, workbenches, general work areas, tyre bays, petrol-pumps & islands, parts washers, pressure washers, dip tanks, toilets, washrooms, public areas, & walk-mats.



Bio-Productions Ltd

72 Victoria Road, Burgess Hill, W Sussex, RH15 9LZ

T: 01444 244000 F: 01444 244999

E: sales@bio-productions.com

W : www.bio-productions.com